
MAIWO

User Manual




KT045 SATA to CFast Convetor

Introduction

Product name:

MAIWO KT045 SATA to CFast Adapter Card




Item name:	MAIWO SATA to CFast Adapter Card
Support:	CFast card
Interface:	CFast
Connector:	SATA
Materials:	PCBA
Features:	Data transmission
Size:	51(L)*45(W)*5.5(H) MM
System:	Windows7/8/10/Mac 10 & 10.5 and above

Quick Installation Guide

1. Installation


1. Insert CFast card into CFast card slot of adapter card.



Quick Installation Guide


1. Installation

2. Connect the adapter board to the spare 7pin data line and 15pin power line in the main box, then turn on the computer.




Ⅰ、New hard disk format:

1. View "computer - Manage - disk management" to Find the new disk .




Ⅰ、New hard disk format:

2. Right click the "External disk", then click "New Simple Volume".




II、Hard disk partition:

3、According to the instruction, choose the size of partition, then click "Next" to finish.



II、Hard disk partition:

4、Then you can find the new hard disk in the "Computer", it's ready to be use.



initialization, partition and format

1.1View "computer - Manage - disk management" to Find the new disk .

Remark: There two types MBR and GPT. SSD capacity <=2T, please choose MBR, if more than 2T, choose GPT.

2.2 Right click the "Disk 1", then click "New Simple Volume".