

Toy Figure User Manual

I. Warning & Safety Information

- ⚠1. This product is not suitable for children under three years
- ⚠2. Do not allow children to play with this product unsupervised.
- ⚠3. Avoid contact with open flames or high-temperature environments.

II. Product Name

- 1. This product is an anime-character figure, intended for collection or display purposes.
- 2. Made of PVC/ABS plastic/plush, featuring exquisite craftsmanship.
- 3. Features multiple articulating joints for pose customization.

III. Instructions for Use

- 1. Upon unpacking, inspect for damage or missing parts.
- 2. Gently wipe surface dust with a soft cloth.
- 3. Display away from direct sunlight and humid environments.

IV. Precautions

- 1. Do not forcefully pull or twist the joints.
- 2. Do not immerse the figure in water for cleaning.
- 3. Adult supervision is required when children are playing with this figure.

V. Function Overview

- 1. Multi-angle articulation enables diverse posing options.
- 2. Premium paint finish with highly realistic detailing.
- 3. Ideal for placement on desks or display shelves.

VI. Frequently Asked Questions (FAQs)

- 1. Unable to articulate: Joints may be temporarily stuck; gently rotate to resolve.
- 2. Surface soiling: Wipe with a dry cloth.
- 3. Parts detached: Contact after-sales service for replacement parts.

VII. After-Sales Service

- 1. Returns or exchanges accepted within 7 days (unused items only).
- 2. Free repair service provided for non-man-made defects within 1 year.