

Smart WiFi Camera Instruction Manual (for AliExpress)

Brand: V360pro

Model: JINYAN7904

SKU: JINYAN 049

This manual is compliant with AliExpress platform requirements and EU regulations (LVD 2014/35/EU & EMC 2014/30/EU). For better user experience, please read this manual carefully before use[3].

1. Product Overview

This smart WiFi camera is a professional security monitoring device, suitable for indoor and outdoor use. It features 1080P HD resolution, night vision, two-way voice intercom, motion detection, and remote viewing via mobile APP. It is compatible with Android, iOS, and MIUI systems, providing you with all-round security protection for your home, shop, or office[6].

Key Features:

-

1080P HD Clear Image: Captures every detail clearly, even in low-light environments.

-

-

Night Vision Function: Equipped with infrared night vision and intelligent fill light, effective monitoring distance up to 30m.

-

-

Two-Way Voice Intercom: Built-in microphone and speaker, enabling real-time communication anytime, anywhere.

-

-

Motion Detection & Alarm: Automatically detects motion and sends real-time alerts to your mobile phone.

-
-

Remote Viewing: Check real-time footage and playback records via mobile APP, supporting 2.4G/5G dual-band WiFi.

-
-

Multiple Storage Options: Supports cloud storage and local storage (not included), with 15/30/60-day cycle recording options.

-

2. Package Contents

-

1 x Smart WiFi Camera

-
-

1 x Power Adapter (EU/US/AU Plug, according to your order)

-
-

1 x Mounting Bracket & Screws

-
-

1 x User Manual (English)

-

Note: Memory card is not included in the package. Please purchase a compatible memory card (Micro SD card, maximum 128GB) if needed.

3. Safety Warnings

Warning! Please read the following warnings carefully to avoid personal injury or product damage[3][4].

-

Do not use the camera in humid environments (such as bathrooms) to prevent short circuits and electric shock.

-

-

Keep the camera away from high temperature, open flames, and corrosive substances to avoid damage to internal components.

-

-

This product is not suitable for children under 36 months old. Keep small parts (such as screws) away from children to prevent accidental ingestion.

-

-

Do not disassemble, repair, or modify the camera by yourself. If there is a fault, contact our after-sales service for professional maintenance.

-

-

Use only the original power adapter provided in the package. Using other adapters may cause overheating or damage to the product.

-

-

Avoid installing the camera in direct sunlight for a long time, which may affect the service life of the lens and image quality.

-

4. Installation & Connection

4.1 Installation Steps

- 1.

Choose a suitable installation location (indoor or outdoor, with stable WiFi signal and no obstruction).

- 2.
- 3.

Fix the mounting bracket to the wall or ceiling using the provided screws.

- 4.
- 5.

Install the camera on the mounting bracket and adjust the angle to ensure the monitoring area is fully covered.

- 6.
- 7.

Connect the power adapter to the camera and plug it into a power outlet. The camera will automatically turn on (the indicator light will flash blue).

- 8.

4.2 WiFi Connection (Mobile APP)

- 1.

Download and install the compatible APP: Search for "Smart Camera" in the App Store (iOS) or Google Play (Android), or scan the QR code on the camera body to download.

- 2.
- 3.

Open the APP and register an account (or log in with an existing account).

- 4.
- 5.

Click "Add Device" in the APP, select "Smart WiFi Camera", and follow the APP prompts to enter your WiFi name and password.

- 6.

7.

Align your mobile phone's camera with the QR code displayed on the APP, and scan the QR code on the camera lens. You will hear a "beep" sound when the scan is successful.

8.

9.

Wait for 1-2 minutes, and the APP will prompt "Connection Successful". Now you can remotely view the camera footage.

10.

Note: If the connection fails, please check whether the WiFi signal is stable, whether the WiFi password is correct, or reset the camera and try again.

5. Usage Instructions

5.1 Basic Operations

-

Real-time Viewing: Open the APP, select the connected camera, and you can view the real-time monitoring footage.

-

-

Two-Way Intercom: Click the "Intercom" button in the APP, and you can talk to the person near the camera in real time.

-

-

Motion Detection: The camera will automatically detect motion in the monitoring area. When motion is detected, it will send an alert to your mobile phone and record the footage (if storage is available).

-

-

Playback: Click the "Playback" button in the APP, select the date and time, and you can view the recorded footage (requires a memory card or cloud storage subscription).

-
-

Night Vision Mode: The camera will automatically switch to night vision mode when the ambient light is dark. You can also manually turn on/off night vision in the APP.

-

5.2 Usage Limitations

-

The camera requires a stable WiFi connection (2.4G/5G) to work normally. Poor WiFi signal will cause lag or disconnection.

-
-

The maximum monitoring distance of night vision is 30m, which may be affected by ambient light and obstacles.

-
-

Do not use the camera to monitor areas with strong electromagnetic interference, which may affect the image and sound quality.

-

6. Maintenance & Care

-

Clean the camera lens regularly with a soft, dry cloth to avoid dust affecting the image quality. Do not use water or corrosive cleaners.

-
-

Turn off the power before cleaning or moving the camera to avoid electric shock.

-
-

If the camera is not used for a long time, disconnect the power and store it in a dry, cool place.

-
-

Regularly update the APP and camera firmware to get better performance and new functions.

-

7. Troubleshooting

Fault Phenomenon	Possible Causes	Solutions
Camera cannot be turned on	Power adapter is not connected properly; power outlet is faulty	Check the power connection; try another power outlet
Failed to connect to WiFi	Incorrect WiFi password; weak WiFi signal; APP version is outdated	Re-enter the correct WiFi password; move the camera closer to the router; update the APP to the latest version
Blurred image	Lens is dirty; monitoring distance is too far; poor light	Clean the lens; adjust the camera angle; turn on fill light or night vision mode
No sound during intercom	Microphone/speaker is blocked; volume is too low	Remove obstacles; adjust the volume in the APP
No motion detection alert	Motion detection function is turned off; monitoring area has no motion; sensitivity is too low	Turn on motion detection in the APP; adjust the monitoring angle; increase the sensitivity

8. After-Sales Service

We provide a 180-day warranty for the camera host and 30-day warranty for accessories (power adapter, bracket, etc.) from the date of receipt[3].
Warranty Scope: The warranty covers product quality defects under normal use. It does not cover damage caused by man-made factors (such as dropping, collision, water ingress), improper use, or unauthorized disassembly.
After-Sales Contact: Please contact our AliExpress store customer service via the AliExpress platform for any questions or issues. We will reply to you within 24 hours and provide professional solutions.

9. Compliance Information

This product complies with the EU Low Voltage Directive (LVD) 2014/35/EU and Electromagnetic Compatibility Directive (EMC) 2014/30/EU, and bears the CE mark in accordance with EU regulations[3].

Product Name: Smart WiFi Camera

Brand: V360pro

Model: JINYAN7904

This manual is in English, and AliExpress will automatically translate it into other languages using AI translation tools (available since February 2026) [3][4].

Thank you for choosing our product! We are committed to providing you with high-quality products and services.