刀线尺寸566X374MM

智能防丢器使用说明书

使用前请仔细阅读此说明书

isearching智能防丢器是集寻找物品和物品防丢为一体的多功能智能设备。它可用于帮助用户寻找物品，如钱包，钥匙，手机，箱包等。同时它具备物品丢失提醒功能。

1.快速操作指南

a. 在APP Store 应用市场搜索isearching或者扫描下面二维码下载APP。
b. 抽出绝缘片，听到滴的一声后表示开机。打开手机蓝牙，进入APP。点击APP右上角的“+”图标添加设备，它将自动连接设备。
c. 连接成功后，向左滑动,找到编辑界面，修改设备名字，头像和开启、关闭防丢功能。

APP应用
二维码

设置完成后就可以直接使用了。

2.如何使用?

将防丢器挂在您想寻找和保护的任何物品上。
使用以下功能必须保持防丢器和APP处于连接状态。
寻找物品功能：按APP界面呼叫按钮，使防丢器发出声音，通过设备发声找到物品。找到物品后，长按设备开关键，可关闭呼叫声。（建议室内使用）。
物品/手机丢失提醒：使用此功能时，请在防丢器的编辑界面打开丢失报警功能。当防丢器和手机离开一段距离并在蓝牙断开连接后，手机和防丢器都会发出报警声。如果物品忘带了，可以及时提醒。如果手机忘带了，也可以及时提醒。
记录物品最后丢失位置功能：物品丢失后，APP将会在地图上记录它的最后丢失位置和时间，定位提供一个大概的位置，方便用户知道到哪里去找。
温馨提示：如果您在使用防丢提醒功能时，感觉到了干扰，请在软件中关闭此功能。

3.支持系统
苹果系统和机型：IOS9.0以上系统，iPhone7以上所有机型.
安卓系统和机型：必须具备安卓9.0及以上系统和蓝牙4.0及以上蓝牙版本机型。
Samsung Galaxy S7 以上机型，Samsung Note 8 , HUAWEI Mate8 以上机型, 荣耀10 以上机型， 小米 7 以上机型。
备注：使用安卓APP，手机必须具备以下两个条件：
1.安卓9.0及以上系统　　2.蓝牙4.0及以上版本
如果你的手机没有在以上列出的机型中，满足安卓9.0系统和蓝牙4.0版的机型也可以使用，但我们不承诺所有机型都可以使用，也不承诺它的使用体验。

4.防丢器开关机和更换电池
开机：抽出绝缘片，听到滴的一声表示开机。
更换电池：此防丢器可更换电池，更换电池如图示。电池为常规3V CR2032 电池，用户可以在淘宝店，遥控器店，电子手表店等店购买。

电池类型

双手按压两边，然后按照图示方向旋转打开电池盖以更换电池。

5.注意事项
a.防丢器不防水，不可将防丢器置入水中。
b.不可将防丢器置入高温环境，将影响防丢器使用性能。
c.不可将防丢器给儿童或者宠物玩耍，以防吞食。
d.防丢器损坏后，不可随意丢弃，应放入回收站避免污染环境。

6.常见问题
1.防丢器的使用范围是多少米?
通常情况下，蓝牙的无线使用距离约为10-50米，由于蓝牙信号受周围环境的影响，其有效范围可能会有所不同。
2.一部手机可以搭配多少个追踪器?
最多可添加4个设备。
3.设备使用时间是多久?
通常，设备可以持续使用180天，电池寿命可能会根据不同的使用情况而变化。当跟踪器连接不稳定时，请更换电池。
4.影响手机与追踪器蓝牙连接稳定性的因素有哪些?
1.手机内存不足。2. 电池低。
3.环境，如天气、金属、同频信号干扰、人体、墙体等。

Smart Finder User Manual

Please read this manual in its entirety before using it.

The isearching smart finder(Bluetooth tracker) is a small multi-function smart device that helps users to find misplaced items such as keys, wallets, bags, phones etc. The iFindU tracker also protects your belongings to prevent loss.

Quick Guide
1. Down load the 'isearching' APP in the App Store or Google Play.
2. Pull out the insulating film. A single beep will sound indicating the device is now on. Open the 'iFindU' APP, tap the '+' icon in the upper left corner of the screen to add the devices, it will connect the application automatically.(Max add up to 4 devices)
3. The slide on the left will show edit and delete buttons. You can edit the device name, picture and turn on/off 'lost reminder' function in the edit interface.

Save the setting and on the go.

How to use
Attach the tracker to anything you want to find and protect.
Make sure your tracker and your phone APP are connected with Bluetooth and within range of each other.
Ring your things: Tap the blue “Ring” button in the application screen, listen for the tracker's ring and find it.
Lost reminder: Select the lost reminder mode in the tracker's edit interface to use this function. When your tracker and your phone is out of Bluetooth's range, both of them will send alerts, and then you will be reminded.
This function may cause annoying, users can use this function accordingly.
Last lost location: When your item is lost, the tracker will put a pin drop on the map where it lost the connection so you know exactly where it went out of Bluetooth range. And you know where to find first.

Compatibility
It is compatible with the following iOS devices running iOS 9.0 and higher:
Phone support: iPhone6 or newer.
It is compatible with most Android devices equipped with Android 9.0 or later and Bluetooth 4.0 or later.

Phone support: Samsung Galaxy S7 or newer Samsung Note 8 , HUAWEI Mate8 or newer, Honor 10 or newer, Redmi 7 or newer.
Notes: In order to run the Android app, your device will need both of the following:
Android 9.0 or higher AND Bluetooth 4.0
If your device is not on this list but uses Android 9.0 and Bluetooth 4.0, it may also work with the application, but we are unable to offer the same level of support.

Power ON and battery replacement
*Power on： Pull out the insulating film. A single beep will sound indicating the device is now on.
*Battery replacement: The battery of this device is replaceable, please refer to the operation view.

Battery type

Press both sides with your hands,and then rotate to open the battery cover to replace the battery.

CAUTION
1.The tracker is not waterproof and can not be placed in water.
2.Do not attach the tracker in a high temperature environment that will affect the performance of the equipment.
3.The tracker contains small parts, please keep them out of reach of young children and pets.
4.If the tracker is damaged, it should not be discarded. It should be put into the recycling station to avoid pollution of the environment.

FAQ：
What is the working range between the tacker and the phone?
Usually the wireless range is around 10-50meters. As a Bluetooth signal will be affected by the surrounding environment, the effective range may vary.
How many trackers can be paired with one phone?
Max add up to 4 devices.
How long does the tracker's battery last?
Usually, the tracker's battery life can be last for180 days, the battery life may vary according to different using circumstances. When the tracker's connection is unstable, please replace the battery.
What are the factors that affect the stability of the Bluetooth connection between your phone and the tracker?
1.The phone has no enough RAM.　　2. Battery low.
3. Environment, such as weather, metal, same frequency signal interference, human body, wall etc.