

Lenovo

X4 Lenovo
骨传导蓝牙耳机



①LED指示灯 ②充电口 ③麦克风
④开关多功能键 ⑤骨传导震子⑥记忆金属后挂

使用说明书
使用前请阅读使用说明书

产品规格

蓝牙版本： V5.0
有效距离： ≥10m
震子直径： Φ16mm
阻抗： 30Ω
麦克风灵敏度： -42dB±3dB
重量： 25g
信噪比： ≥50dB
充电时长： 约2H
频率响应： 20Hz-20KHz
播放时长： 约7小时
电池容量： 150mAh
额定输入： 5V $\overline{=}$ 110mA
协议： A2DP,AVRCP,HSP,HFP
(所有技术信息以实际性能为准)

物品清单

骨传导耳机 x 1
充电线 x 1
说明书 x 1

产品使用简介

- 除说明书有特殊标示的操作方式以外，请勿尝试拆卸或更换产品内的任何零件。
- 请勿将产品放入水或其他任何液体中，此产品非防水设计。
- 如果有任何液体不小心进入产品内时，请立即断开连接并移开此产品，继续使用有可能会一起起火或触电。
- 为避免触电，请在安装或卸载产品时，确保手上没有沾水。
- 请勿将此产品放置于热源附近或直接暴露在火源附近。
- 请勿将本产品放置在有强大电磁力的环境中，否则会导致产品故障。

产品操作说明

- 开机
手动开机：在关机状态下，长按触摸键3-5秒红蓝灯交替闪，开机
- 关机
手动关机：在开机状态下，长按触摸键3-5秒，指示灯熄灭，关机
- 播放暂停
暂停播放：在播放状态下，触摸或滑动触摸键1次
- 来电状态
接听电话：接听来电，单击耳机触摸键
挂断电话：结束通话，单击耳机触摸键
- 播放音乐
上一曲：快速双击耳机触摸键，播放上一曲
下一曲：快速三击耳机触摸键，播放下一曲
音量调节：打开手机播放器调节，音量逐渐增大变小(播放音乐状态)

6.激活SIRI
长按住骨传导耳机触摸键1S启动SIRI语音助手功能(需要所连接智能设备支持语音助手)

7.指示灯说明：
红蓝交替：配对状态
蓝色呼吸：连接成功等待播放状态
红色常亮：正在充电
蓝色常亮：电池充满

8.蓝牙链接
首次使用，耳机正常开机后，会进入蓝牙配对状态，此时手机设置里可以搜索到Lenovo-X4，点击链接成功后指示灯蓝灯闪烁，播放音乐蓝灯熄灭。

9.更换配对设备及回连
断开当前配对设备，耳机指示灯红蓝交替闪，其他设备即可搜索到Lenovo-X4，点击连接。联想X4骨传导蓝牙耳机支持回连，开机3-5秒即会回连最后一次连接的设备。

10.充电指示
手机会显示耳机电量，电量不足时手机会显示红框提醒，同时耳机会出现Low power 提示音，即耳机电量不足，插入USB充电即可。正在充电则红灯常亮，电量充满则绿灯常亮。

产品中有害物质名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
印刷电路组件	×	○	○	○	○	○
外壳等小结构件	×	○	○	○	○	○
本表格依据SJ/T 11364的规定编制。 ○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以下。 ×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572 规定的限量要求。 表单标记“X”的部件，皆因全球技术发展水平限制而无法实现有害物质的替代。						
印刷电路板组件*：包括印刷电路板及其零部件，电子元器件等，根据产品型号不同，您所购买的产品可能不会含有以上所有部件						
	在中华人民共和国境内销售的电子电气产品必须标识此标志，标志内的数字代表在正常的使用状态下的产品的环保使用期限。					



保修声明

免责声明
本使用手册没有任何形式的担保、立场表达或其他暗示，本使用手册所提到的产品、规格及信息仅供参考，内容亦会随时更新于网页，恕不另行通知。

保修声明：
就本文件附随的产品做如下保证：如产品在您购买日起十二（12）个月（“保修期”）内，在正常使用情况下因质量瑕疵发生损坏，能修理的，免费修理；经厂家确认无法修理的，免费更换；修理或更换后的产品，在剩余保修期（最短不少于30天）内继续享有保修。购买日以销售发票日期为准；如无法确定购买日，则保修期自产品生产日期起按十三（13）个月计算。
如申请保修，请先致电产品服务热线，并按我们指示的方式执行。申请保修时，您需要提供准确、完整和清晰填写的有效销售发票。

以上保证不适用于下列情况：
1.超过三包有效期的；
2.涂改保修卡、产品编码与产品本体不符；
3.因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏；
4.因不可抗力（如地震、战争、火灾等）或意外导致的故障或损坏；
5.拉链、塔扣因受力过大而损坏；
6.因承载过重造成的脱线或断裂；
7.任何因尖锐物体造成的损坏；
8.有烧损或水浸迹象的产品；
9.因擅自拆改导致的损坏；
10.产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损耗。

保修声明

11.如产品原有标识标签被更改或损毁，本保证将失效。
产品及随附物料的齐备和外观完好不属于保证范围，您应在接收产品时当场检验并对任何不符提出异议。

以上保证是我们就产品做出的全部保证，且仅在中國大陸地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权利。

售后邮箱: frank@szeyan.cn
售后服务电话: 400-812-0102

“联想”、“Lenovo”、“Lenovo联想”及其他联想标识是联想集团所属企业的商标。（本材料）提及的其他商标、公司名称、产品或服务名称可能是联想集团所属企业或其他公司的商标。
版权所有（c）2021 联想（北京）有限公司保留所有权利。

Lenovo

Lenovo

X4 Lenovo
BONE CONDUCTION HEADPHONE



①LED indicator light ②Charging port ③Microphone
④MFB(Multi-function button) ⑤Bone conduction vibrator
⑥Silicone memory neckband

USER MANUAL
Please read this manual carefully before using the headphones.

PRODUCT SPECIFICATION

Bluetooth version:V5.0
Connection range: ≥10m
Driver size: Φ16mm
Impedance: 30Ω
Microphone sensitivity: -42dB±3dB
Weight: 25g
Signal-to-noise ratio: ≥50dB
Charging time: 2H
Frequency response: 20Hz-20KHz
Playback time: about 7hours
Battery capacity: 150mAh
Input: 5V $\overline{=}$ 110mA
Protocol: A2DP, AVRCP, HSP, HFP
(All technical information is subject to actual performance)

PACKING LIST

Bone conduction headphone* 1
USB charging cable*1
User manual*1

PRODUCT INTRODUCTION

- Except for the operation methods specifically marked in the manual, please do not try to disassemble or replace any parts in the headphone.
- Do not put the earbuds in water or any other liquid. The headphones are not waterproof.
- If any liquid accidentally enters the headphone, please immediately disconnect and remove the headset. If you continue to use them, they may cause fire or electric shock.

- (4) To avoid electric shock, please make sure that there is no water on your hands when installing or uninstalling the headphone.
- (5) Do not place the headphone near a heat source or directly expose them to a fire source.
- (6) Do not place the headphone in an environment with strong electromagnetic force, otherwise they will malfunction.

OPERATION INSTRUCTIONS

- Power on
Auto power-on:
In the shutdown state, press and hold on the MFB for 3-5 seconds, and the red and blue lights will flash alternately to turn on the headphone.
- Power off
Auto power-off: In the power-on state, press and hold on the MFB for 3-5 seconds, the indicator light will go out, and the headphone will be turned off
- Pause/ Play
In the play/pause state, touch or slide the MFB once on right panel.
- Incoming call status
Answer a call: Once -click the MFB button
Reject a call: Twice-click the MFB button
- Play music

Previous song: Quickly double-click the headset MFB to play the previous song
Next song: Quickly click the headset MFB three times to play the next song

Volume adjustment: Turn on the mobile phone player to adjust, the volume gradually increases and decreases (music playing state)

6. Activate Siri
Long press and hold on the bone conduction headset MFB 1s to start the Siri voice assistant function (need the support of the connected smart device)

7. Description of indicator light:
Red blue Alternation: pairing state
Blue light breathing: connected successfully and waiting for playback.
Red light always on: Need to recharge
Blue light always on: Finished charging

8. Bluetooth link
After the headset is turned on normally for the first time, it will enter the Bluetooth pairing state. At this time, the mobile phone will In the settings, search Lenove-X4 and click to connect the device ,the indicator light will turn to blue when connected successfully. Blue light turns off when in playing status.

9. Replacement of paired equipment and connection back
Disconnect the current device, the indicator will flash red and blue alternately, and other devices will search to Lenove-X4 then click Connect. Lenove-X4 supports reconnection, it will reconnect for the last connected device 3-5 seconds after booting up.

10. Charging indication
The battery capacity of the headphone will be displayed on the phone. When the headset prompts "Low power", it indicates that the battery is low. Please charge the headphone in time.

THE NAME AND CONTENT OF HARMFUL SUBSTANCES IN THE EARBUDS

Names	Harmful Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
PCBA components	×	○	○	○	○	○
Structural components	×	○	○	○	○	○
This form is compiled in accordance with SJ/T 11364. ○：Indicates that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572. X：Indicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572. The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances. Printed circuit board components: Including printed circuit boards and their parts, electronic components, etc. and depending on the product model, the earbuds you purchased may not contain all the above components.						
	Electronic and electrical products sold in the People's Republic of China must mark this Logo, the number in the logo represents the product under normal use Environmental protection use period.					



WARRANTY STATEMENT

Disclaimer
This user manual does not have any form of guarantee, position expression or other implication.
The mentioned products, specifications and information are for reference only, and the content will also be updated on the web at any time without additional separate notice
Warranty statement:
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired, Free repair; free replacement if the manufacturer confirms that it cannot be repaired; repaired or replaced product. Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchased by sale The ticket date shall prevail; if the purchase date cannot be determined, the warranty period shall be 13 (13) Monthly calculation.
If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice. The above guarantee does not apply to the following situations:
1. Exceeding the validity period of the three packs;
2. Altering the warranty card and product code does not match the product body;
3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storage Obstacles or damage;
4. Failure or damage caused by force majeure (such as earthquake, war, disaster, etc.) or accident Bad;

WARRANTY STATEMENT

5. The zipper and tower buckle are damaged due to excessive force;
6. Disconnection or tearing caused by excessive load;
7. Any damage caused by sharp objects;
8. Products with signs of burning or flooding;
9. Damage caused by unauthorized disassembly;
10. Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product.
Warranty statement
11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.
The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should Check on the spot and raise objections to any discrepancies.
The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China
. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law
Profit.
After-sales mailbox: frank@szeyan.cn
After-sales service telephone: 400-812-0102
"Lenovo", "Lenovo", "Lenovo Lenovo" and other Lenovo logos are Lenovo Group The trademark of the affiliated company. (This material) mentioned other trademarks, company names, products or services
The name may be a trademark of a Lenovo Group company or another company. Copyright (c) 2021 Lenovo (Beijing) Co., Ltd. All rights reserved.

Lenovo