

EJEAS Type-C Referee Intercom Headset User Manual

(For EJEAS V4 Plus, F6, V7 Referee Intercom)

1. Product Overview

This Type-C headset is a dedicated audio accessory for EJEAS referee intercom systems (V4 Plus/F6/V7), designed for clear communication during sports officiating (e.g., football, basketball). It features an ear-hook design for stable wear, a noise-reducing microphone, and a long cable to pair with the EJEAS arm pack.

2. Compatible Devices

This headset is exclusively compatible with:

- EJEAS V4 Plus Referee Intercom
- EJEAS F6 Referee Intercom
- EJEAS V7 Referee Intercom
- EJEAS Referee Intercom Arm Pack (for carrying the intercom device)

3. Component Description

Component	Function
Ear-Hook Headset	Over-ear design for stable wear during active officiating; soft earpiece ensures comfort.
Noise-Reducing Microphone	Foam-wrapped mic reduces background noise (e.g., crowd, sports field sounds) for clear voice transmission.
Cable Clip	Fixes the cable to clothing (e.g., referee jersey) to prevent tangling during movement.
Type-C Connector	Connects to EJEAS intercom device (or arm pack's Type-C port) for audio signal transmission.
Long Cable (Tangle-Resistant)	Extended length (adapted to referee arm pack placement) with tied design to avoid mess.

4. Installation & Connection Guide

4.1 Connecting to EJEAS Intercom/Arm Pack

1. Locate the **Type-C port** on your EJEAS intercom (V4 Plus/F6/V7) or its matching arm pack.
2. Insert the headset's Type-C connector into the port—ensure a tight fit (the intercom will recognize the headset automatically).

4.2 Wearing the Headset

1. Hook the **ear-hook design** over your preferred ear (left/right, based on referee habit).
2. Adjust the earpiece to fit snugly (ensure it does not fall off during quick movements like running).

3. Position the **noise-reducing microphone** 1-2cm from your mouth (for optimal voice pickup).

4.3 Securing the Cable

1. Use the **cable clip** to fasten the headset cable to your referee jersey (route the cable along the shoulder/chest area).
2. Store the excess cable in the EJEAS arm pack (to avoid interference during officiating).

5. Usage Tips (For Referee Scenarios)

1. **Noise Reduction:** Ensure the microphone's foam cover is intact (it blocks environmental noise on the field).
2. **Cable Management:** Avoid pulling the cable during quick movements—use the clip to keep it fixed.
3. **Communication Test:** Before officiating, test the headset with the intercom to confirm clear audio input/output.

6. Maintenance & Care

1. **Cleaning:** Wipe the earpiece and microphone foam with a dry soft cloth (do not wash with water).
2. **Cable Care:** Avoid bending the cable at sharp angles; untie the cable gently when storing.
3. **Storage:** Disconnect the headset from the intercom after use, and store it in a dry, dust-free bag.

7. After-Sales Support

- **Warranty Period:** 6 months from purchase (covers manufacturing defects of the headset).
- **Warranty Exclusions:** Damage caused by cable pulling, water exposure, or improper ear-hook bending is not covered.
- **Contact:** For support, reach out to EJEAS's official after-sales channel or the retailer.