

Quick User Guide

WiFi Camera

Available on the App Store

GET IT ON Google Play

Download CAM720 APP from APP store or Google play, or by Scanning the QR code above.

Sign up an account by email and login, please read the instructions carefully before use.

Camera introduction

Note: The reset button position will be different for different models, and the picture is for reference only

1

2

3

Q1:What should I pay attention to before WiFi connection?

A1:APP permission: PIs turn on GPS and all permissions,select"allow"; iOS iPhone,pls enable location action by setting<privacy>location ser vice>can't 720 APP>enable,pls location,select "always"; WiFi requirement: PIs ensure the Name and password of the router are not more than 16 characters Note: pls take the camera near the router for first connection,cellphone connected the same wifi

Q2:What should I pay attention to before Wired connection?

A2:Ethernet cable:pls check the cable is working and check the indicator of the network port is always on NOTE: pls confirm the cellphone connected the same wifi of the router that camera connected.

Q3:How to do if the camera is often offline?

A3:Adapter: pls check the adapter and outlet for the camera,or check the camera's record, if there are some broken records, the problem is in power,camera can record without wifi Network: pls check the network, is it normal APP permission: pls check mobile network permission on the APP is enable, otherwise, the APP can't work under mobile network. Reconfigure the camera: delete the camera from the APP> add the camera after reset the camera as the first connection

4

Sign up & Login

1.Register an account: Click"sign up"> enter Email, set your APP's pass word, check the verified code

2.Login

Note: if you don't want register an account, it can't remote, but you can use stand alone mode to view the camera. This mode only support Local view

5

WiFi connection

Power and Reset the camera: PIs plug the adapter for the camera. Reset the camera by long press the reset button for 7-5 seconds until you hearing "Di~",camera will do self-inspection after "Di~"2 times Requirement Before WiFi connection: pls read Q1 above; Don't ban permissions of the APP

NOTE: some models only support 2.4GHz WiFi, cellphone connected 2.4G WiFi for first connection; if camera support 2.4GHz dual-band WiFi, pls choose the right WiFi according to the place you want to install (2.4GHz signal transfer distances longer, 5GHz is shorter but faster in speed).

The device connects to the router via WiFi

6

1.In the APP: click"*"> select"WiFi connection"

2.Check "configure the network when you hear the device tone"> Tap"next step"

7

3.Follow the Tips Shown in the APP(pls connect WiFi to JAA-*** or JAA-***, and then back to Cam720 APP)to find the Camera's WiFi(namedJAA-** / JAA-***),after connected it pls back to cam720 APP

8

4. Enter the right password of the WiFi that your phone connected to, Tap"Next Step"

5. When the device is connected, pls wait patiently until camera is online",then click the video to view

9

Bluetooth configuration

1. Please confirm that the Bluetooth function is turned on.

2. After resetting the camera, wait for it "Di~"two sounds, until camera completes self-test.

3. In the APP: Click "*" and wait for 1-2 seconds for the APP to automatically search for the camera Bluetooth signal.

10

4. Select the Bluetooth signal of the camera, input the WiFi password and click Next.

5. Wait patiently during Bluetooth network configuration, please do not exit halfway.

Note: Please ignore if you don't need for Bluetooth network configuration. If you need to use it again, please close APP then re-open.

11

Wired Connection

Plug the power supply and Ethernet cable to the router: PIs plug the adapter for the camera, and connect the camera with the Ethernet cable to the router

Reset the camera: Long-press the reset button about 5-8s until you hearing Prompted, select wired connection to connect it.

NOTE: pls read Q2 above if there is a problem in wired connection if the camera has a Network port, it supports wired WiFi connection, otherwise, pls select wifi connection to connect

Connect to the router LAN port through a network cable

12

1. In the APP,click"*"> select "network cable connection"

2. Search and select the IP of the camera,click to add

3. Click the video to view until hearing "camera is online"

13

1. Return to the device list

2. Share the device

3. More function settings

4. Switch image effects

5. Turn on the microphone

6. Screenshot to save the image

7. Switch into Full-screen image

8.Playback (SD card Playback / Cloud Playback)

9. Setting of cruise

10. Preset point settings

11. T2P-rotation control

12. Turn on voice intercom

13. Turn on screen record function

1. Start Live video

2. Subscribe Cloud storage

3. More functions setup

4. User information

5. Modify the device name

6. Add more cameras

14

1. Back to the device list

2. Modify the device name

3. Share equipment

4. SD card setup

5. Detection alarm settings

6. Buy cloud storage

7. Image Flip: upside down

8. Choose a call mode

9. Enable/Disable Auto tracking

10.Indicator light switch

11. Choose night vision mode

12. Set the time zone

13. Switch WiFi network

14. Camera information

15. Camera version number

16. Delete the camera

17.Transfer the camera to another account

15

Share

Share your camera with your friends and families

1.Your friend should have an account of cam720 APP.

2.in main account, enter the Email of the friend APP account or scan the QR code of the account to share it.

3. Freely set the permission on this shared account.

16

Playback

1.Turn on the playback function and two Record method available: SDcard record(8-128G) and Cloud Record.

2.New users can get a trial cloud storage for free,pls don't miss it.

3.SD card record supports 3 record modes: 24/7 continuous, motion-triggered, scheduled record.

17

Installation

Indoor Camera-stent assembly

1.This camera can be placed on the desktop, or do cell or Wall mounted.

2.Attach the bracket to the wall and make a mark on the hole to punch holes, and use a 6mm drill bit to get the holes,then Stuff the rubber stopper into the hole.

3.Align the bracket with the hole position and tighten the screws. Fix the body, hold the body and turn it tightly.

18

1. This camera can be placed on the desktop, or do cell or Wall mounted.

2. Attach the bracket to the wall and make a mark on the hole to punch holes, and use a 6mm drill bit to get the holes,then Stuff the rubber stopper into the hole.

3.Align the bracket with the hole position and tighten the screws. Fix the body, hold the body and turn it tightly.

19

Outdoor camera

1.Put the other end of bracket A together with the slot of bracket B, and then just push it down.

2.Select a suitable location and install expansion screws on the wall. for example, if it's a wooden wall,expansion screws are not requirement.

3.Align the bracket with the hole position and tighten the screws.

Note: Different models will have different appearance and installation method, the picture is for reference only

20

Important Use Notice

1. The use of unapproved or incompatible power adapters may cause fire, explosion or other dangers.

2.This product and accessories contain some small parts to avoid children contact and cause swallowing small parts, causing suffocation or other hazards, in addition, this product is not a toy, children should be used under adult supervision.

3.Please use this product within the appropriate temperature range. When the ambient temperature is too high or too low, it may cause errors, avoid rain or moisture on the product and its accessories, so as not to affect the use of the product.

4. Suitable for equipment, suitable for areas with an altitude of 2000 meters and below.

5.WIFI device should be under a good wifi signal area,pls avoid choosing a closed environment installation which may cause bad signal.

21

Important Use Notice

1.Failed in connection at first connection? PIs view the operation video at last page(Scan the QR code to view), and pls view wifi connection steps from Page6, if all failed, pls message seller to get support,we also offer online support if you need.

2.Change a router, camera is offline? pls delete the camera from the APP, and take the camera to near the new router power and reset it, search and add it.

3.Stop record? 1.Check the status of the SD card in the APP 2.Check the record setup support 3.format SD card 4.change a SD card to test 5.message Seller to get

4.Camera is offline? Read the Q3 at page6 and follow it to check, if there is further question, pls message seller to get support.

5.The instructions are not detailed enough? It's general quick user guide,so less many details,pls contact seller to get the E-user manual and operation video according to your order.

22

After-sale Service & Tech Support

We offer a one-year warranty and lifetime technical support! As long as there is any problem, please feel free to contact the purchase store, we will quickly provide an effective solution.

E-mail: technicalreply@gacv.com market@gacv.com

By scanning the QR code below to access Youtube, Select the right operation video for your camera according to APP and Model of the camera Or message seller to get the operation video directly.

Operation videos (Scan the QR code to view)

23